

CARE AND MAINTENANCE

Basic precautions and care will insure that your VersaCourt surface will maintain its appearance and optimum performance for many years. These tips are not expensive and do not take a lot of time, but can do a lot to protect your investment for future use.

MAINTENANCE CLEANING:

VersaCourt tile can be cleaned in a variety of ways. If it is an outdoor application, leaves, sticks, and trash can build up on the surface. A leaf blower can be used to remove most debris. If the tile surface is dusty or dirty then a power washer can be used – be sure to set it on a low-pressure setting and do not directly spray the painted lines.

Over time dirt, leaves, rocks and other debris may accumulate under the tile. If this does occur to the point where the tile is full, unsnap the tiles in large sections and slide the tile out of the way to clean the subsurface.

Precautions:

- Keep any kind of flame (cigarettes, charcoal grills, fireworks, etc.) away from the surface.
- Keep surface free of leaves, grass clippings, or other debris. A good leaf blower works well to help keep the surface clean.
- Be careful when using any type of edging tools near the edge of the surface.
- VersaCourt will resist the harmful effects of rain, snow, and ice. Some color loss is inherent in the product and will not affect the quality of the surface.
- Surface cleaning equipment, such as leaf blowers, will exude heat, do not to place these tools on the tile as damage may occur to the surface.

REPLACING TILES:

Tiles are replaced in a matter of seconds. Insert a hook or screwdriver into a hole closest to the corner of the tile which does not have receivers and pull up.